**TROLEX** 

# COMPLIANCE PACK<sup>+</sup>

QUICK START

Register your warranty online at www.trolex.com/register



# 1. XXD1<sup>+</sup> REQUIRES COMPLIANCE CHECK

The flashing lights shown and an intermittent audio beep tell you your **XXD1**<sup>+</sup> is ready for a compliance check.









© Trolex LTD All Rights Reserved

#### 2. DOWNLOAD

Download the **BreatheLITE** software on to your Mac or PC device.

Otrolex.com/breathelite-download

#### 3. CONNECT

Connect your **XCD1**<sup>+</sup> directly to your computer using the USB cable.







## 4. COMPLIANCE BASE

Place your **XCD1**<sup>+</sup> in a Trolex compliance base ready for the compliance check.

Ensure the clear hood is fitted over the top and the unit is connected to your computer.

#### 5. PREPARE SAMPLE

Decant the Trolex approved sample into the application bottle.







## 6. START YOUR CHECK

Select "Compliance check" on **BreatheLITE**.

### 7. SAMPLE

Introduce sample and follow the on-screen instructions.



## A





## 8. PASSED

Great, you're good to go for another 3 months.

\*Please consult the user manual if you need to retest your **XXD1**<sup>+</sup>.

#### 9. DON'T FORGET

You can order more compliance samples through your local approved distributor.





Scan the QR code to find your local Trolex partner.

